



Button Size Information

Choose the right size button with these helpful hints.....

Place your button on top of the closest corresponding button picture (below) to determine size.

Remember, buttons should be smaller than button holes to allow buttoning ease.

Use this general button fashion guide to help chose the correct button size:

1/4" (7mm) - Childrenswear, Shirts, Smocking

3/8" (9mm) - Childrenswear Shirts Blouses

1/2" (13mm) - Childrenswear, Shirts, Blouses, Dresses

5/8" (16mm) - Blouses, Dresses, Vests, Cuffs, Skirts

3/4" (19mm) - Dresses, Skirts, Jackets

7/8" (22mm) - Dresses, Skirts, Jackets

1" (25mm) - Dresses, Skirts, Coats, Raincoats

1-1/8" (28mm) and up - Skirts, Coats


button size chart



44mm
1-3/4"



34mm
1-3/8"



27mm
1-1/8"




25mm
1"



22mm
7/8"



20mm
13/16"



19mm
3/4"



18mm
11/16"



15mm
5/8"



12mm
1/2"



11.5mm
7/16"



8 mm
5/16"